



NOTES:

1. INSTALL ANODE A MINIMUM OF 2-FEET BELOW PIPE DEPTH IN NATIVE SOIL.
2. MAXIMUM HORIZONTAL DISTANCE FROM ANODE TO LEAK REPAIR CLAMP IS 5-FEET.

CITY OF NAPA

PUBLIC WORKS - WATER DIVISION

LEAK REPAIR CLAMP - ANODE INSTALLATION

DATE REVISED DECEMBER 2015

CHECKED

APPROVED

SCALE

NONE

DWG NO.

W - 24D